



OWNER'S MANUAL

Drag Star

**XVS650
XVS650A**

5BN-28199-E1

Welcome to the Yamaha world of motorcycling!

As the owner of an XVS650/XVS650A, you are benefiting from Yamaha's vast experience and newest technology regarding the design and manufacture of high-quality products, which have earned Yamaha a reputation for dependability.

Please take the time to read this manual thoroughly, so as to enjoy all advantages of your XVS650's. The owner's manual does not only instruct you in how to operate, inspect and maintain your motorcycle, but also in how to safeguard yourself and others from trouble and injury.

In addition, the many tips given in this manual will help keep your motorcycle in the best possible condition. If you have any further questions, do not hesitate to contact your Yamaha dealer.

The Yamaha team wishes you many safe and pleasant rides. So, remember to put safety first!

IMPORTANT MANUAL INFORMATION

Particularly important information is distinguished in this manual by the following notations:



The Safety Alert Symbol means **ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!**



Failure to follow **WARNING** instructions could result in severe injury or death to the motorcycle operator, a bystander, or a person inspecting or repairing the motorcycle.

CAUTION:

A **CAUTION** indicates special precautions that must be taken to avoid damage to the motorcycle.

NOTE:

A **NOTE** provides key information to make procedures easier or clearer.

NOTE:

- This manual should be considered a permanent part of this motorcycle and should remain with it even if the motorcycle is subsequently sold.
 - Yamaha continually seeks advancements in product design and quality. Therefore, while this manual contains the most current product information available at the time of printing, there may be minor discrepancies between your motorcycle and this manual. If you have any questions concerning this manual, please consult your Yamaha dealer.
-

IMPORTANT MANUAL INFORMATION

EW000002

 **WARNING**

PLEASE READ THIS MANUAL CAREFULLY AND COMPLETELY BEFORE OPERATING THIS MOTORCYCLE.

IMPORTANT MANUAL INFORMATION

EAU03337

**XVS650/XVS650A
OWNER'S MANUAL
© 2000 by Yamaha Motor Co., Ltd.
1st Edition, August 2000
All rights reserved.
Any reprinting or unauthorized use
without the written permission of
Yamaha Motor Co., Ltd.
is expressly prohibited.
Printed in Japan.**

1 GIVE SAFETY THE RIGHT OF WAY	1
2 DESCRIPTION	2
3 INSTRUMENT AND CONTROL FUNCTIONS	3
4 PRE-OPERATION CHECKS	4
5 OPERATION AND IMPORTANT RIDING POINTS	5
6 PERIODIC MAINTENANCE AND MINOR REPAIR	6
7 MOTORCYCLE CARE AND STORAGE	7
8 SPECIFICATIONS	8
9 CONSUMER INFORMATION	9
INDEX	



GIVE SAFETY THE RIGHT OF WAY

GIVE SAFETY THE RIGHT OF WAY 1-1



Motorcycles are fascinating vehicles, which can give you an unsurpassed feeling of power and freedom. However, they also impose certain limits, which you must accept; even the best motorcycle does not ignore the laws of physics.

Regular care and maintenance are essential for preserving value and operating condition of your motorcycle. Moreover, what is true for the motorcycle is also true for the rider: good performance depends on being in good shape. Riding under the influence of medication, drugs and alcohol is, of course, out of the question. Motorcycle riders—more than car drivers—must always be at their mental and physical best. Under the influence of even small amounts of alcohol, there is a tendency to take dangerous risks.

Protective clothing is as essential for the motorcycle rider as seat belts are for car drivers and passengers. Always wear a complete motorcycle suit (whether made of leather or tear-resistant synthetic materials with protectors), sturdy boots, motorcycle gloves and a properly fitting helmet. Optimum protective wear, however, should not encourage carelessness. Although full-coverage helmets and suits, in particular, create an illusion of total safety and protection, motorcyclists will always be vulnerable. Riders who lack critical self-control run the risk of going too fast and are apt to take chances. This is even more dangerous in wet weather. The good motorcyclist rides safely, predictably and defensively—avoiding all dangers, including those caused by others.

Enjoy your ride!

Left view (XVS650)	2-1
Right view (XVS650)	2-2
Left view (XVS650A)	2-3
Right view (XVS650A).....	2-4
Controls and instruments (XVS650/XVS650A)	2-5

Left view (XVS650)


2



- 1. Shift pedal (page 3-5)
- 2. Fuel cock (page 3-8)
- 3. Starter (choke) knob (page 3-9)
- 4. Shock absorber spring preload adjusting ring (page 3-14)

- 5. Helmet holder (page 3-12)
- 6. Storage compartment (page 3-13)
- 7. Owner's tool kit (page 6-1)

Right view (XVS650)




- 8. Engine oil filter element (page 6-9)
- 9. Battery (page 6-29)
- 10. Fuses (page 6-31)
- 11. Main switch/steering lock (page 3-1)
- 12. Air filter element (page 6-13)
- 13. Brake pedal (page 3-6)

DESCRIPTION

Left view (XVS650A)


2



- 1. Shift pedal (page 3-5)
- 2. Fuel cock (page 3-8)
- 3. Starter (choke) knob (page 3-9)
- 4. Shock absorber spring preload adjusting ring (page 3-14)

- 5. Helmet holder (page 3-12)
- 6. Storage compartment (page 3-13)
- 7. Owner's tool kit (page 6-1)

Right view (XVS650A)




- 8. Engine oil filter element (page 6-9)
- 9. Battery (page 6-29)
- 10. Fuses (page 6-31)
- 11. Main switch/steering lock (page 3-1)
- 12. Air filter element (page 6-13)
- 13. Brake pedal (page 3-6)

DESCRIPTION

Controls and instruments (XVS650/XVS650A)


2



- | | |
|-----------------------------|-------------|
| 1. Clutch lever | (page 3-5) |
| 2. Left handlebar switches | (page 3-3) |
| 3. Speedometer unit | (page 3-3) |
| 4. Fuel tank cap | (page 3-7) |
| 5. Right handlebar switches | (page 3-4) |
| 6. Throttle grip | (page 6-15) |
| 7. Brake lever | (page 3-6) |

INSTRUMENT AND CONTROL FUNCTIONS

Main switch/steering lock	3-1
Indicator and warning lights	3-2
Speedometer unit	3-3
Anti-theft alarm (optional)	3-3
Handlebar switches	3-3
Clutch lever	3-5
Shift pedal (XVS650).....	3-5
Shift pedal (XVS650A)	3-5
Brake lever	3-6
Brake pedal	3-6
Fuel tank cap	3-7
Fuel	3-7
Fuel cock	3-8
Starter (choke) knob	3-9
Seats (XVS650)	3-10
Seats (XVS650A)	3-11
Helmet holder	3-12
Storage compartment	3-13
Adjusting the shock absorber assembly	3-14
Luggage strap holders	3-15
Sidestand	3-15
Ignition circuit cut-off system	3-16



EAU00029

Main switch/steering lock

The main switch/steering lock controls the ignition and lighting systems, and is used to lock the steering. The various positions are described below.

ON


EAU00036

All electrical systems are supplied with power, and the engine can be started. The key cannot be removed.

OFF

EAU00038

All electrical systems are off. The key can be removed.



EAU00040

LOCK


The steering is locked, and all electrical systems are off. The key can be removed.

To lock the steering

1. Turn the handlebars all the way to the left.
2. Push the key in from the "OFF" position, and then turn it to "LOCK" while still pushing it.
3. Remove the key.

To unlock the steering

Push the key in, and then turn it to "OFF" while still pushing it.



1. Push.
2. Turn.

EW000016

! WARNING

Never turn the key to "OFF" or "LOCK" while the motorcycle is moving, otherwise the electrical systems will be switched off, which may result in loss of control or an accident. Make sure that the motorcycle is stopped before turning the key to "OFF" or "LOCK".

INSTRUMENT AND CONTROL FUNCTIONS

P_⊥ (Parking)


EAU00044




The steering is locked, and the taillight is on, but all other electrical systems are off. The key can be removed. The steering must be locked before the key can be turned to “P_⊥”.

ECA00043

CAUTION:

Do not use the parking position for an extended length of time, otherwise the battery may discharge.



1. High beam indicator light “”
2. Turn signal indicator light “”
3. Neutral indicator light “**N**”
4. Engine trouble warning light “”

Indicator and warning lights

EAU03034

Turn signal indicator light “”

EAU00057

This indicator light flashes when the turn signal switch is pushed to the left or right.

Neutral indicator light “**N**”

EAU00061

This indicator light comes on when the transmission is in the neutral position.

High beam indicator light “”

EAU00063

This indicator light comes on when the high beam of the headlight is switched on.

Engine trouble warning light “”

EAU03182


This warning light comes on or flashes when an electrical circuit monitoring the engine is defective. When this occurs, have the Yamaha dealer check the self-diagnosis system.

NOTE:

This warning light comes on for a few seconds when the key is turned to “ON”, but this does not indicate a malfunction.

INSTRUMENT AND CONTROL FUNCTIONS

3



1. Tripmeter reset knob
2. Speedometer
3. Odometer
4. Tripmeter

Speedometer unit


EAU00095

The speedometer unit is equipped with a speedometer, an odometer and a tripmeter. The speedometer shows riding speed. The odometer shows the total distance traveled. The tripmeter shows the distance traveled since it was last set to zero with the reset knob. The tripmeter can be used to estimate the distance that can be traveled with a full tank of fuel. This information will enable you to plan future fuel stops.

EAU00109

Anti-theft alarm (optional)

This motorcycle can be equipped with an optional anti-theft alarm by a Yamaha dealer. Contact a Yamaha dealer for more information.



1. Turn signal switch
2. Pass switch “≡D”
3. Dimmer switch
4. Horn switch “📣”

Handlebar switches

EAU00118

Turn signal switch

EAU00127

To signal a right-hand turn, push this switch to “⇨”. To signal a left-hand turn, push this switch to “⇧”. When released, the switch returns to the center position. To cancel the turn signal lights, push the switch in after it has returned to the center position.

INSTRUMENT AND CONTROL FUNCTIONS



Pass switch “”

EAU00119

Press this switch to flash the headlight.

Dimmer switch


EAU00121


Set this switch to “” for the high beam and to “” for the low beam.

Horn switch “”

EAU00129

Press this switch to sound the horn.



1. Start switch “”
2. Engine stop switch
3. Light switch

Start switch “”

EAU00143

Push this switch to crank the engine with the starter.


EC000005

CAUTION:

See page 5-1 for starting instructions prior to starting the engine.





Engine stop switch

EAU00138

Set this switch to “” to stop the engine in case of an emergency, such as when the motorcycle overturns or when the throttle cable is stuck.


Light switch

EAU00134

Set this switch to “  ” to turn on the auxiliary light, meter lighting and tail-light. Set the switch to “” to turn on the headlight also.

INSTRUMENT AND CONTROL FUNCTIONS

3




1. Clutch lever

EAU00152

Clutch lever

The clutch lever is located at the left handlebar grip. To disengage the clutch, pull the lever toward the handlebar grip. To engage the clutch, release the lever. The lever should be pulled rapidly and released slowly for smooth clutch operation.

The clutch lever is equipped with a clutch switch, which is part of the ignition circuit cut-off system. (See page 3-16 for an explanation of the ignition circuit cut-off system.)




1. Shift pedal

EAU00157

Shift pedal (XVS650)

The shift pedal is located on the left side of the engine and is used in combination with the clutch lever when shifting the gears of the 5-speed constant-mesh transmission equipped on this motorcycle.



1. Shift pedal


EAU01215

Shift pedal (XVS650A)

The shift pedal is located on the left side of the engine and is used in combination with the clutch lever when shifting the gears of the 5-speed constant-mesh transmission equipped on this motorcycle.

NOTE: _____
Use your toes or heel to shift up and your toes to shift down.

INSTRUMENT AND CONTROL FUNCTIONS




1. Brake lever

EAU00158

Brake lever

The brake lever is located at the right handlebar grip. To apply the front brake, pull the lever toward the handlebar grip.




1. Brake pedal

EAU00162

Brake pedal


The brake pedal is on the right side of the motorcycle. To apply the rear brake, press down on the brake pedal.



1. Brake pedal

INSTRUMENT AND CONTROL FUNCTIONS

3



1. “△” mark
2. Unlock.

EAU00169

Fuel tank cap

To remove the fuel tank cap

Insert the key into the lock and turn it 1/4 turn clockwise. The lock will be released and the fuel tank cap can be removed.

To install the fuel tank cap

1. Insert the fuel tank cap into the tank opening with the key inserted in the lock and with the “△” mark facing forward.
2. Turn the key counterclockwise to the original position, and then remove it.


NOTE:

The fuel tank cap cannot be installed unless the key is in the lock. In addition, the key cannot be removed if the cap is not properly installed and locked.

EW000024

WARNING

Make sure that the fuel tank cap is properly installed before riding.



1. Fuel tank filler tube
2. Fuel level

EAU01183

Fuel

Make sure that there is sufficient fuel in the tank. Fill the fuel tank to the bottom of the filler tube as shown in the illustration.

EW000130

WARNING

- Do not overfill the fuel tank, otherwise it may overflow when the fuel warms up and expands.
- Avoid spilling fuel on the hot engine.

INSTRUMENT AND CONTROL FUNCTIONS

EAU00185

CAUTION:

Immediately wipe off spilled fuel with a clean, dry, soft cloth, since fuel may deteriorate painted surfaces or plastic parts.

EAU00191

Recommended fuel:


Regular unleaded gasoline with a research octane number of 91 or higher

Fuel tank capacity:


Total amount:
16 L
Reserve amount:
3 L

NOTE:

If knocking (or pinging) occurs, use gasoline of a different brand or with a higher octane grade.



1. Arrow mark positioned over "OFF"



1. Arrow mark positioned over "ON"

EAU02969

Fuel cock

The fuel cock supplies fuel from the tank to the carburetors while also filtering it.

The fuel cock lever positions are explained as follows and shown in the illustrations.

OFF


With the fuel cock lever in this position, fuel will not flow. Always turn the fuel cock lever to this position when the engine is not running.

ON

With the fuel cock lever in this position, fuel flows to the carburetors. Turn the fuel cock lever to this position when starting the engine and riding.

INSTRUMENT AND CONTROL FUNCTIONS


ECA00038



1. Arrow mark positioned over "RES"

RES

This indicates reserve. With the fuel cock lever in this position, the fuel reserve is made available. Turn the fuel cock lever to this position if you run out of fuel while riding. When this occurs, refuel as soon as possible and be sure to turn the fuel cock lever back to "ON"!



1. Starter (choke) knob "V"

Starter (choke) knob

EAU03031

Starting a cold engine requires a richer air-fuel mixture, which is supplied by the starter (choke).


Move the knob in direction **a** to turn on the starter (choke).

Move the knob in direction **b** to turn off the starter (choke).

CAUTION:

Do not use the starter (choke) for more than 3 minutes as the exhaust pipe may discolor from excessive heat. In addition, extended use of the starter (choke) will cause after-burning. If this occurs, turn off the starter (choke).

INSTRUMENT AND CONTROL FUNCTIONS



1. Nut


EAU01889

Seats (XVS650)

Passenger seat

To remove the passenger seat


Remove the nut, and then pull the passenger seat up.



1. Bolt (× 2)
2. Seat holder
3. Projection

To install the passenger seat

Insert the projection on the front of the passenger seat into the seat holder as shown, place the seat in the original position, and then install the nut.



1. Seat holder
2. Projection

Rider seat

To remove the rider seat

1. Remove the passenger seat.
2. Remove the bolts, and then pull the seat up.


To install the rider seat

1. Insert the projection on the front of the rider seat into the seat holder as shown, place the seat in the original position, and then install the bolts.
2. Install the passenger seat.

NOTE: _____
Make sure that the seats are properly secured before riding.

INSTRUMENT AND CONTROL FUNCTIONS

XVS650A



1. Bolt

EAU01888


Seats (XVS650A)

Passenger seat

To remove the passenger seat

Remove the bolt, and then pull the passenger seat up.

XVS650A




1. Seat holder (× 2)
2. Projection (× 2)

To install the passenger seat

Insert the projections on the front of the passenger seat into the holder as shown, place the seat in the original position, and then install the bolt.

XVS650A



1. Bolt


Rider seat

To remove the rider seat

1. Remove the passenger seat.
2. Remove the bolt, and then pull the rider seat up.

INSTRUMENT AND CONTROL FUNCTIONS

XVS650A




1. Seat holder
2. Projection

To install the rider seat

1. Insert the projection on the front of the rider seat into the holder as shown, place the seat in the original position, and then install the bolt.
2. Install the passenger seat.

NOTE: _____
Make sure that the seats are properly secured before riding.



1. Helmet holder
2. Unlock.

Helmet holder

EAU00260

To open the helmet holder, insert the key into the lock, and then turn the key as shown.

To lock the helmet holder, place it in the original position, and then remove the key.


EW000030

WARNING

Never ride with a helmet attached to the helmet holder, since the helmet may hit objects, causing loss of control and possibly an accident.

INSTRUMENT AND CONTROL FUNCTIONS

3




1. Storage compartment cover
2. Storage compartment lock cover
3. Storage compartment lock

Storage compartment


EAU01869

The storage compartment is located on the left side of the motorcycle.



To open the storage compartment

1. Slide the lock cover open, insert the key into the lock, and then turn it clockwise.
2. Pull the storage compartment cover out as shown.




1. Storage compartment
2. Storage compartment cover

To close the storage compartment

1. Place the storage compartment cover in its original position as shown.
2. Turn the key counterclockwise, remove it, and then close the lock cover.

INSTRUMENT AND CONTROL FUNCTIONS

EC000015



1. Position indicator
2. Spring preload adjusting ring
3. Extension bar
4. Special wrench

EAU00299

Adjusting the shock absorber assembly

This shock absorber assembly is equipped with a spring preload adjusting ring.

CAUTION:

Never attempt to turn an adjusting mechanism beyond the maximum or minimum settings.

Adjust the spring preload as follows.

1. Remove the passenger and rider seats. (See page 3-10 [XVS650] or 3-11 [XVS650A] for removal and installation procedures.)
2. To increase the spring preload and thereby harden the suspension, turn the adjusting ring in direction ①. To decrease the spring preload and thereby soften the suspension, turn the adjusting ring in direction ②.

NOTE:

- Align the appropriate notch in the adjusting ring with the position indicator on the shock absorber.
- Use the special wrench and extension bar included in the owner's tool kit to make the adjustment.

Setting	Minimum (soft)		Standard	Maximum (hard)			
	1	2	3	4	5	6	7

3. Install the passenger and rider seats.


INSTRUMENT AND CONTROL FUNCTIONS

EAU00315

⚠ WARNING

This shock absorber contains highly pressurized nitrogen gas. For proper handling, read and understand the following information before handling the shock absorber. The manufacturer cannot be held responsible for property damage or personal injury that may result from improper handling.

- Do not tamper with or attempt to open the gas cylinder.
- Do not subject the shock absorber to an open flame or other high heat sources, otherwise it may explode due to excessive gas pressure.
- Do not deform or damage the gas cylinder in any way, as this will result in poor damping performance.
- Always have a Yamaha dealer service the shock absorber.



1. Luggage strap holder (× 2)

EAU01172

Luggage strap holders

There is a luggage strap holder on each passenger footrest.

EAU00330

Sidestand

The sidestand is located on the left side of the frame. Raise the sidestand or lower it with your foot while holding the motorcycle upright.

NOTE:

The built-in sidestand switch is part of the ignition circuit cut-off system, which cuts the ignition in certain situations. (See further down for an explanation of the ignition circuit cut-off system.)

EW000044

EAU03720

WARNING

The motorcycle must not be ridden with the sidestand down, or if the sidestand cannot be properly moved up (or does not stay up), otherwise the sidestand could contact the ground and distract the operator, resulting in a possible loss of control. Yamaha's ignition circuit cut-off system has been designed to assist the operator in fulfilling the responsibility of raising the sidestand before starting off. Therefore, check this system regularly as described below and have a Yamaha dealer repair it if it does not function properly.

Ignition circuit cut-off system

The ignition circuit cut-off system (comprising the sidestand switch, clutch switch and neutral switch) has the following functions.

- It prevents starting when the transmission is in gear and the sidestand is up, but the clutch lever is not pulled.
- It prevents starting when the transmission is in gear and the clutch lever is pulled, but the sidestand is still down.
- It cuts the running engine when the transmission is in gear and the sidestand is moved down.

Periodically check the operation of the ignition circuit cut-off system according to the following procedure.


EW000045

WARNING

If a malfunction is noted, have a Yamaha dealer check the system before riding.

INSTRUMENT AND CONTROL FUNCTIONS

3



Pre-operation check list 4-1

PRE-OPERATION CHECKS

The condition of a vehicle is the owner's responsibility. Vital components can start to deteriorate quickly and unexpectedly, even if the vehicle remains unused (for example, as a result of exposure to the elements). Any damage, fluid leakage or loss of tire air pressure could have serious consequences. Therefore, it is very important, in addition to a thorough visual inspection, to check the following points before each ride.

Pre-operation check list

ITEM	CHECKS	PAGE
Fuel	<ul style="list-style-type: none">• Check fuel level in fuel tank.• Refuel if necessary.• Check fuel line for leakage.	3-7-3-8
Engine oil	<ul style="list-style-type: none">• Check oil level in engine.• If necessary, add recommended oil to specified level.• Check vehicle for oil leakage.	6-9-6-11
Final gear oil	<ul style="list-style-type: none">• Check vehicle for oil leakage.	6-11-6-12
Front brake	<ul style="list-style-type: none">• Check operation.• If soft or spongy, have Yamaha dealer bleed hydraulic system.• Check lever free play.• Adjust if necessary.• Check fluid level in reservoir.• If necessary, add recommended brake fluid to specified level.• Check hydraulic system for leakage.	6-20-6-21, 6-23-6-25
Rear brake	<ul style="list-style-type: none">• Check operation.• Check pedal free play.• Adjust if necessary.	6-21-6-25
Clutch	<ul style="list-style-type: none">• Check operation.• Lubricate cable if necessary.• Check lever free play.• Adjust if necessary.	6-19-6-20
Throttle grip	<ul style="list-style-type: none">• Make sure that operation is smooth.• Lubricate throttle grip, housing and cables if necessary.• Check free play.• If necessary, have Yamaha dealer make adjustment.	6-15, 6-25

PRE-OPERATION CHECKS

ITEM	CHECKS	PAGE
Control cables	<ul style="list-style-type: none"> • Make sure that operation is smooth. • Lubricate if necessary. 	6-25
Wheels and tires	<ul style="list-style-type: none"> • Check for damage. • Check tire condition and tread depth. • Check air pressure. • Correct if necessary. 	6-16–6-19
Brake and shift pedals	<ul style="list-style-type: none"> • Make sure that operation is smooth. • Lubricate pedal pivoting points if necessary. 	6-26
Brake and clutch levers	<ul style="list-style-type: none"> • Make sure that operation is smooth. • Lubricate lever pivoting points if necessary. 	6-26
Sidestand	<ul style="list-style-type: none"> • Make sure that operation is smooth. • Lubricate pivot if necessary. 	6-27
Chassis fasteners	<ul style="list-style-type: none"> • Make sure that all nuts, bolts and screws are properly tightened. • Tighten if necessary. 	—
Instruments, lights, signals and switches	<ul style="list-style-type: none"> • Check operation. • Correct if necessary. 	—
Sidestand switch	<ul style="list-style-type: none"> • Check operation of ignition circuit cut-off system. • If system is defective, have Yamaha dealer check vehicle. 	3-15–3-16

NOTE:

Pre-operation checks should be made each time the motorcycle is used. Such an inspection can be accomplished in a very short time; and the added safety it assures is more than worth the time involved.

EWA00033



If any item in the Pre-operation check list is not working properly, have it inspected and repaired before operating the motorcycle.

OPERATION AND IMPORTANT RIDING POINTS

Starting the engine	5-1
Starting a warm engine	5-2
Shifting	5-3
Tips for reducing fuel consumption	5-4
Engine break-in	5-4
Parking	5-5

EAU00373

⚠ WARNING

- Become thoroughly familiar with all operating controls and their functions before riding. Consult a Yamaha dealer regarding any control or function that you do not thoroughly understand.
- Never start the engine or operate it in a closed area for any length of time. Exhaust fumes are poisonous, and inhaling them can cause loss of consciousness and death within a short time. Always make sure that there is adequate ventilation.
- Before starting out, make sure that the sidestand is up. If the sidestand is not raised completely, it could contact the ground and distract the operator, resulting in a possible loss of control.

Starting the engine

EAU03461*


In order for the ignition circuit cut-off system to enable starting, one of the following conditions must be met:

- The transmission is in the neutral position.
- The transmission is in gear with the clutch lever pulled and the sidestand up.

EW000054

⚠ WARNING

- Before starting the engine, check the function of the ignition circuit cut-off system according to the procedure described on page 3-17.
- Never ride with the sidestand down.



1. Turn the fuel cock lever to "ON".
2. Turn the key to "ON" and make sure that the engine stop switch is set to "⊙".
3. Shift the transmission into the neutral position.


NOTE:

When the transmission is in the neutral position, the neutral indicator light should be on, otherwise have a Yamaha dealer check the electrical circuit.

4. Turn the starter (choke) on and completely close the throttle. (See page 3-9 for starter (choke) operation.)

OPERATION AND IMPORTANT RIDING POINTS

EAU01258



5. Start the engine by pushing the start switch.

NOTE: _____
If the engine fails to start, release the start switch, wait a few seconds, and then try again. Each starting attempt should be as short as possible to preserve the battery. Do not crank the engine more than 10 seconds on any one attempt.

ECA00059

CAUTION: _____
If the oil level warning light flickers or remains on after starting, immediately stop the engine, and then check the engine oil level and the

vehicle for oil leakage. If necessary, add engine oil, and then check the warning light again. If the warning light does not go off after starting with sufficient engine oil, have a Yamaha dealer check the electrical circuit.

6. After starting the engine, move the starter (choke) knob back halfway.

ECA00055

CAUTION: _____
For maximum engine life, always warm the engine up before starting off. Never accelerate hard when the engine is cold!


7. When the engine is warm, turn the starter (choke) off.

NOTE: _____
The engine is warm when it responds normally to the throttle with the starter (choke) turned off.

Starting a warm engine


Follow the same procedure as for starting a cold engine with the exception that the starter (choke) is not required when the engine is warm.

OPERATION AND IMPORTANT RIDING POINTS



1. Shift pedal
N. Neutral position

EAU00423



1. Shift pedal
N. Neutral position

EC000048

- Always use the clutch while changing gears to avoid damaging the engine, transmission, and drive train, which are not designed to withstand the shock of forced shifting.

5

Shifting

Shifting gears lets you control the amount of engine power available for starting off, accelerating, climbing hills, etc.

The gear positions are shown in the illustration.

NOTE:

To shift the transmission into the neutral position, press the shift pedal down repeatedly until it reaches the end of its travel, and then slightly raise it.

CAUTION:

- Even with the transmission in the neutral position, do not coast for long periods of time with the engine off, and do not tow the motorcycle for long distances. The transmission is properly lubricated only when the engine is running. Inadequate lubrication may damage the transmission.

OPERATION AND IMPORTANT RIDING POINTS

Tips for reducing fuel consumption

EAU00424

Fuel consumption depends largely on your riding style. Consider the following tips to reduce fuel consumption:

- Thoroughly warm up the engine.
- Turn the starter (choke) off as soon as possible.
- Shift up swiftly, and avoid high engine speeds during acceleration.
- Do not rev the engine while shifting down, and avoid high engine speeds with no load on the engine.
- Turn the engine off instead of letting it idle for an extended length of time (e.g., in traffic jams, at traffic lights or at railroad crossings).

Engine break-in

EAU01128

There is never a more important period in the life of your engine than the period between 0 and 1,600 km. For this reason, you should read the following material carefully.

Since the engine is brand new, do not put an excessive load on it for the first 1,600 km. The various parts in the engine wear and polish themselves to the correct operating clearances. During this period, prolonged full-throttle operation or any condition that might result in engine overheating must be avoided.

0–1,000 km

Avoid prolonged operation above 1/3 throttle.

1,000–1,600 km

Avoid prolonged operation above 1/2 throttle.

EAU01171*

EC000056*

CAUTION:

After 1,000 km of operation, the engine oil and final gear oil must be changed, and the oil filter element replaced.

1,600 km and beyond

The vehicle can now be operated normally.

EC000049

CAUTION:

If any engine trouble should occur during the engine break-in period, immediately have a Yamaha dealer check the vehicle.

OPERATION AND IMPORTANT RIDING POINTS

EAU00457

Parking

When parking, stop the engine, remove the key from the main switch, and then turn the fuel cock lever to “OFF”.

EW000058

WARNING

- Since the engine and exhaust system can become very hot, park in a place where pedestrians or children are not likely to touch them.
 - Do not park on a slope or on soft ground, otherwise the motorcycle may overturn.
-

PERIODIC MAINTENANCE AND MINOR REPAIR

Owner's tool kit	6-1	Checking and lubricating the cables	6-25
Periodic maintenance and lubrication chart	6-2	Checking and lubricating the throttle grip and cable	6-25
Removing and installing panels	6-5	Checking and lubricating the brake and shift pedals	6-26
Checking the spark plugs	6-7	Checking and lubricating the brake and clutch levers	6-26
Engine oil and oil filter element	6-9	Checking and lubricating the sidestand	6-27
Final gear oil	6-11	Checking the front fork	6-27
Cleaning the air filter element	6-13	Checking the steering	6-28
Adjusting the carburetors	6-14	Checking the wheel bearings	6-29
Adjusting the engine idling speed	6-15	Battery	6-29
Adjusting the throttle cable free play	6-15	Replacing the fuses	6-31
Adjusting the valve clearance	6-16	Replacing the headlight bulb	6-32
Tires	6-16	Replacing a turn signal light bulb or the tail/brake light bulb	6-33
Spoke wheels	6-19	Supporting the motorcycle	6-34
Adjusting the clutch lever free play	6-19	Front wheel	6-35
Adjusting the brake lever free play	6-20	Rear wheel	6-36
Adjusting the brake pedal position and free play	6-21	Troubleshooting	6-38
Adjusting the rear brake light switch	6-22	Troubleshooting chart	6-39
Checking the front brake pads and rear brake shoes	6-23		
Checking the brake fluid level	6-24		
Changing the brake fluid	6-25		

EAU00464

Safety is an obligation of the owner. Periodic inspection, adjustment and lubrication will keep your vehicle in the safest and most efficient condition possible. The most important points of inspection, adjustment, and lubrication are explained on the following pages. The intervals given in the periodic maintenance and lubrication chart should be simply considered as a general guide under normal riding conditions. However, **DEPENDING ON THE WEATHER, TERRAIN, GEOGRAPHICAL LOCATION, AND INDIVIDUAL USE, THE MAINTENANCE INTERVALS MAY NEED TO BE SHORTENED.**

EW000060

⚠ WARNING

If you are not familiar with motorcycle maintenance work, have a Yamaha dealer do it for you.

EAU01129

Owner's tool kit

The owner's tool kit is located inside the storage compartment. (See page 3-13 for storage compartment opening procedures.)

The service information included in this manual and the tools provided in the owner's tool kit are intended to assist you in the performance of preventive maintenance and minor repairs. However, additional tools such as a torque wrench may be necessary to perform certain maintenance work correctly.

NOTE:

If you do not have the tools or experience required for a particular job, have a Yamaha dealer perform it for you.

EW000063

⚠ WARNING

Modifications not approved by Yamaha may cause loss of performance and render the vehicle unsafe for use. Consult a Yamaha dealer before attempting any changes.

PERIODIC MAINTENANCE AND MINOR REPAIR

EAU03685

Periodic maintenance and lubrication chart

NOTE:

- The annual checks must be performed every year, except if a kilometer-based maintenance is performed instead.
- From 50,000 km, repeat the maintenance intervals starting from 10,000 km.
- Items marked with an asterisk should be performed by a Yamaha dealer as they require special tools, data and technical skills.

NO.	ITEM	CHECK OR MAINTENANCE JOB	ODOMETER READING (×1,000 km)					ANNUAL CHECK
			1	10	20	30	40	
1	* Fuel line	• Check fuel hoses for cracks or damage.		√	√	√	√	√
2	* Fuel filter	• Check condition.			√		√	
3	Spark plugs	• Check condition. • Clean and regap.		√		√		
		• Replace.			√		√	
4	* Valves	• Check valve clearance. • Adjust.		√	√	√	√	
5	Air filter element	• Clean.		√		√		
		• Replace.			√		√	
6	Clutch	• Check operation. • Adjust.	√	√	√	√	√	
7	* Front brake	• Check operation, fluid level and vehicle for fluid leakage. (See NOTE on page 6-4.)	√	√	√	√	√	√
		• Replace brake pads.	Whenever worn to the limit					
8	* Rear brake	• Check operation and adjust brake pedal freeplay.	√	√	√	√	√	√
		• Replace brake shoes.	Whenever worn to the limit					
9	* Brake hose	• Check for cracks or damage.		√	√	√	√	√
		• Replace. (See NOTE on page 6-4.)	Every 4 years					

PERIODIC MAINTENANCE AND MINOR REPAIR

NO.	ITEM	CHECK OR MAINTENANCE JOB	ODOMETER READING (×1,000 km)					ANNUAL CHECK
			1	10	20	30	40	
10	* Wheels	<ul style="list-style-type: none"> • Check runout, spoke tightness and for damage. • Tighten spokes if necessary. 		√	√	√	√	
11	* Tires	<ul style="list-style-type: none"> • Check tread depth and for damage. • Replace if necessary. • Check air pressure. • Correct if necessary. 		√	√	√	√	
12	* Wheel bearings	<ul style="list-style-type: none"> • Check bearing for looseness or damage. 		√	√	√	√	
13	* Swingarm	<ul style="list-style-type: none"> • Check operation and for excessive play. 		√	√	√	√	
		<ul style="list-style-type: none"> • Lubricate with molybdenum disulfide grease. 	Every 50,000 km					
14	* Steering bearings	<ul style="list-style-type: none"> • Check bearing play and steering for roughness. 	√	√	√	√	√	
		<ul style="list-style-type: none"> • Lubricate with lithium-soap-based grease. 	Every 20,000 km					
15	* Chassis fasteners	<ul style="list-style-type: none"> • Make sure that all nuts, bolts and screws are properly tightened. 		√	√	√	√	√
16	Sidestand	<ul style="list-style-type: none"> • Check operation. • Lubricate. 		√	√	√	√	√
17	* Sidestand switch	<ul style="list-style-type: none"> • Check operation. 	√	√	√	√	√	√
18	* Front fork	<ul style="list-style-type: none"> • Check operation and for oil leakage. 		√	√	√	√	
19	* Rear shock absorber assembly	<ul style="list-style-type: none"> • Check operation and shock absorber for oil leakage. 		√	√	√	√	
20	* Carburetors	<ul style="list-style-type: none"> • Check starter (choke) operation. • Adjust engine idling speed and synchronization. 	√	√	√	√	√	√
21	Engine oil	<ul style="list-style-type: none"> • Change. 	√	√	√	√	√	√
22	Engine oil filter element	<ul style="list-style-type: none"> • Replace. 	√		√		√	
23	Final gear oil	<ul style="list-style-type: none"> • Check oil level and vehicle for oil leakage. 	√	√		√		
		<ul style="list-style-type: none"> • Change. 	√		√		√	
24	* Front and rear brake switches	<ul style="list-style-type: none"> • Check operation. 	√	√	√	√	√	√
25	Moving parts and cables	<ul style="list-style-type: none"> • Lubricate. 		√	√	√	√	√

PERIODIC MAINTENANCE AND MINOR REPAIR


NO.	ITEM	CHECK OR MAINTENANCE JOB	ODOMETER READING ($\times 1,000$ km)					ANNUAL CHECK	
			1	10	20	30	40		
26	*	Lights, signals and switches	• Check operation. • Adjust headlight beam.	√	√	√	√	√	√

EAU03541

NOTE:


- The air filter needs more frequent service if you are riding in unusually wet or dusty areas.
- Hydraulic brake service
 - Regularly check and, if necessary, correct the brake fluid level.
 - Every two years replace the internal components of the brake master cylinder and caliper, and change the brake fluid.
 - Replace the brake hoses every four years and if cracked or damaged.

PERIODIC MAINTENANCE AND MINOR REPAIR




1. Panel A

EAU01122



1. Panel B



1. Bolt (× 4)

EAU01573

Removing and installing panels

The panels shown above need to be removed to perform some of the maintenance jobs described in this chapter. Refer to this section each time a panel needs to be removed and installed.

Panel A


To remove the panel

Remove the bolts, and then take the panel off.

To install the panel

Place the panel in the original position, and then install the bolts.

PERIODIC MAINTENANCE AND MINOR REPAIR




1. Bolt

EAU00491

Panel B

To remove the panel


Remove the bolt, and then pull the panel off as shown.



To install the panel

Place the panel in the original position, and then install the bolt.

PERIODIC MAINTENANCE AND MINOR REPAIR




1. Spark plug cap

EAU03329

Checking the spark plugs

The spark plugs are important engine components, which are easy to check. Since heat and deposits will cause any spark plug to slowly erode, the spark plugs should be removed and checked in accordance with the periodic maintenance and lubrication chart. In addition, the condition of the spark plugs can reveal the condition of the engine.



1. Spark plug wrench

To remove a spark plug

1. Remove the spark plug cap.
2. Remove the spark plug as shown, with the spark plug wrench included in the owner's tool kit.

To check the spark plugs

1. Check that the porcelain insulator around the center electrode on each spark plug is a medium-to-light tan (the ideal color when the motorcycle is ridden normally).
2. Check that all spark plugs installed in the engine have the same color.


NOTE:

If any spark plug shows a distinctly different color, the engine could be defective. Do not attempt to diagnose such problems yourself. Instead, have a Yamaha dealer check the motorcycle.

3. Check each spark plug for electrode erosion and excessive carbon or other deposits, and replace it if necessary.

Specified spark plug:
DPR7EA-9 (NGK) or
X22EPR-U9 (DENSO)

PERIODIC MAINTENANCE AND MINOR REPAIR



a. Spark plug gap

To install a spark plug

1. Measure the spark plug gap with a wire thickness gauge and, if necessary, adjust the gap to specification.

Spark plug gap:
0.8–0.9 mm

2. Clean the surface of the spark plug gasket and its mating surface, and then wipe off any grime from the spark plug threads.
3. Install the spark plug with the spark plug wrench, and then tighten it to the specified torque.

Tightening torque:
Spark plug:
20 Nm (2.0 m·kg)

NOTE: _____
If a torque wrench is not available when installing a spark plug, a good estimate of the correct torque is 1/4–1/2 turn past finger tight. However, the spark plug should be tightened to the specified torque as soon as possible.

4. Install the spark plug cap.

PERIODIC MAINTENANCE AND MINOR REPAIR

EAU03835

Engine oil and oil filter element


The engine oil level should be checked before each ride. In addition, the oil must be changed and the oil filter element replaced at the intervals specified in the periodic maintenance and lubrication chart.

To check the engine oil level

1. Place the motorcycle on a level surface and hold it in an upright position.

NOTE: _____
Make sure that the motorcycle is positioned straight up when checking the oil level. A slight tilt to the side can result in a false reading.

2. Start the engine, warm it up for several minutes, and then turn it off.




1. Engine oil level check window
2. Maximum level mark
3. Minimum level mark
4. Engine oil filler cap

3. Wait a few minutes until the oil settles, and then check the oil level through the check window located at the bottom-left side of the crankcase.

NOTE: _____
The engine oil should be between the minimum and maximum level marks.

4. If the engine oil is below the minimum level mark, add sufficient oil of the recommended type to raise it to the correct level.




1. Engine oil drain bolt
2. Oil pan


To change the engine oil (with or without oil filter element replacement)

1. Start the engine, warm it up for several minutes, and then turn it off.
2. Place an oil pan under the engine to collect the used oil.
3. Remove the engine oil filler cap and drain bolt to drain the oil from the crankcase.


PERIODIC MAINTENANCE AND MINOR REPAIR



1. Outer oil filter element cover
2. Bolt (× 3)



1. Inner oil filter element cover
2. Bolt (× 5)



1. Oil filter element
2. O-ring

NOTE:

Skip steps 4–7 if the oil filter element is not being replaced.

4. Remove the outer and inner oil filter element covers by removing the bolts.

5. Remove the oil filter element and O-ring.
6. Install a new oil filter element and the O-ring.
7. Install the oil filter element covers by installing the bolts.
8. Install the engine oil drain bolt, and then tighten it to the specified torque.

Tightening torque:
Engine oil drain bolt:
43 Nm (4.3 m·kg)

PERIODIC MAINTENANCE AND MINOR REPAIR

9. Add the specified amount of the recommended oil, and then install and tighten the oil filler cap.

Recommended engine oil:

See page 8-1.

Oil quantity:

Without oil filter element replacement:

2.6 L

With oil filter element replacement:

2.8 L

Total amount (dry engine):

3.2 L

EC000072

EAU02943*

CAUTION:

- **In order to prevent clutch slippage (since the engine oil also lubricates the clutch), do not mix any chemical additives with the oil or use oils of a higher grade than “CD”. In addition, do not use oils labeled “ENERGY CONSERVING II” or higher.**
- **Make sure that no foreign material enters the crankcase.**

10. Start the engine, and then let it idle for several minutes while checking it for oil leakage. If oil is leaking, immediately turn the engine off and check for the cause.
11. Turn the engine off, and then check the oil level and correct it if necessary.

Final gear oil

The final gear case must be checked for oil leakage before each ride. If any leakage is found, have a Yamaha dealer check and repair the motorcycle. In addition, the final gear oil level must be checked and the oil changed as follows at the intervals specified in the periodic maintenance and lubrication chart.

EW000066


WARNING

- **Make sure that no foreign material enters the final gear case.**
- **Make sure that no oil gets on the tire or wheel.**

To check the final gear oil level

1. Place the motorcycle on a level surface and hold it in an upright position.

PERIODIC MAINTENANCE AND MINOR REPAIR



1. Final gear oil drain bolt
2. Final gear oil filler bolt
3. Correct oil level

NOTE: _____

- The final gear oil level must be checked on a cold engine.
- Make sure that the motorcycle is positioned straight up when checking the oil level. A slight tilt to the side can result in a false reading.

2. Remove the oil filler bolt, and then check the oil level in the final gear case.

NOTE: _____
The oil level should be at the brim of the filler hole.

3. If the oil is below the brim of the filler hole, add sufficient oil of the recommended type to raise it to the correct level.

To change the final gear oil

1. Place an oil pan under the final gear case to collect the used oil.
2. Remove the oil filler bolt and drain bolt to drain the oil from the final gear case.
3. Install the final gear oil drain bolt, and then tighten it to the specified torque.

Tightening torque:
Final gear oil drain bolt:
23 Nm (2.3 m·kg)

4. Add the recommended final gear oil to the brim of the filler hole.

Recommended final gear oil:
See page 8-2.
Oil quantity:
0.19 L


NOTE: _____
GL4 is a quality rating. Hypoid gear oils rated GL5 or GL6 may also be used.

5. Install and tighten the filler bolt to the specified torque.

Tightening torque:
Final gear oil filler bolt:
23 Nm (2.3 m·kg)

6. Check the final gear case for oil leakage. If oil is leaking, check for the cause.

PERIODIC MAINTENANCE AND MINOR REPAIR




1. Air filter case cover
2. Screw (× 3)

EAU00586*


Cleaning the air filter element

The air filter element should be cleaned at the intervals specified in the periodic maintenance and lubrication chart. Clean the air filter element more frequently if you are riding in unusually wet or dusty areas.


1. Remove the air filter case cover by removing the screws.
2. Pull the air filter element out.



1. Air filter element
3. Lightly tap the air filter element to remove most of the dust and dirt, and then blow the remaining dirt out with compressed air as shown. If the air filter element is damaged, replace it.



1. Air filter element holder
2. Projection
3. Slot
4. Insert the air filter element into the air filter case as shown.



1. Match marks

EC000082*

EAU00630

Adjusting the carburetors

The carburetors are important parts of the engine and require very sophisticated adjustment. Therefore, most carburetor adjustments should be left to a Yamaha dealer, who has the necessary professional knowledge and experience. The adjustment described in the following section, however, may be serviced by the owner as part of routine maintenance.

EC000095

CAUTION:

- Make sure that the air filter element is properly seated in the air filter case.
- The engine should never be operated without the air filter element installed, otherwise the pistons and/or cylinders may become excessively worn.

CAUTION:

The carburetors have been set and extensively tested at the Yamaha factory. Changing these settings without sufficient technical knowledge may result in poor performance of or damage to the engine.

5. Install the air filter case cover by aligning the match marks and installing the screws.

PERIODIC MAINTENANCE AND MINOR REPAIR

EAU01168

Adjusting the engine idling speed

The engine idling speed must be checked and, if necessary, adjusted as follows at the intervals specified in the periodic maintenance and lubrication chart.


NOTE:

A diagnostic tachometer is needed to make this adjustment.

1. Attach the tachometer to the spark plug lead.
2. Start the engine and warm it up for several minutes at 1,000–2,000 r/min while occasionally revving it to 4,000–5,000 r/min.

NOTE:

The engine is warm when it quickly responds to the throttle.




1. Throttle stop screw

3. Check the engine idling speed and, if necessary, adjust it to specification by turning the throttle stop screw. To increase the engine idling speed, turn the screw in direction **a**. To decrease the engine idling speed, turn the screw in direction **b**.

Engine idling speed:
1,150–1,250 r/min

NOTE:

If the specified idling speed cannot be obtained as described above, have a Yamaha dealer make the adjustment.



a. Throttle cable free play

EAU00635


Adjusting the throttle cable free play

The throttle cable free play should measure 4–6 mm at the throttle grip. Periodically check the throttle cable free play and, if necessary, have a Yamaha dealer adjust it.

EAU00637

Adjusting the valve clearance

The valve clearance changes with use, resulting in improper air-fuel mixture and/or engine noise. To prevent this from occurring, the valve clearance must be adjusted by a Yamaha dealer at the intervals specified in the periodic maintenance and lubrication chart.



1. Tire sidewall
- a. Tire tread depth

EAU03362

Tires

To maximize the performance, durability, and safe operation of your motorcycle, note the following points regarding the specified tires.

Tire air pressure

The tire air pressure should be checked and, if necessary, adjusted before each ride.

EW000082

! WARNING

- The tire air pressure must be checked and adjusted on cold tires (i.e., when the temperature of the tires equals the ambient temperature).
- The tire air pressure must be adjusted in accordance with the riding speed and with the total weight of rider, passenger, cargo, and accessories approved for this model.

XVS650

Tire air pressure (measured on cold tires)		
Load*	Front	Rear
Up to 90 kg	200 kPa (2.00 kg/cm ² , 2.00 bar)	225 kPa (2.25 kg/cm ² , 2.25 bar)
90 kg–maximum	200 kPa (2.00 kg/cm ² , 2.00 bar)	250 kPa (2.50 kg/cm ² , 2.50 bar)

Maximum load*	180 kg
---------------	--------

* Total weight of rider, passenger, cargo and accessories

PERIODIC MAINTENANCE AND MINOR REPAIR

XVS650A

Tire air pressure (measured on cold tires)		
Load*	Front	Rear
Up to 90 kg	225 kPa (2.25 kg/cm ² , 2.25 bar)	225 kPa (2.25 kg/cm ² , 2.25 bar)
90 kg–maximum	225 kPa (2.25 kg/cm ² , 2.25 bar)	250 kPa (2.50 kg/cm ² , 2.50 bar)

Maximum load*	200 kg
---------------	--------

* Total weight of rider, passenger, cargo and accessories

EWA00012

WARNING

Because loading has an enormous impact on the handling, braking, performance and safety characteristics of your motorcycle, you should keep the following precautions in mind.

- **NEVER OVERLOAD THE MOTORCYCLE!** Operation of an overloaded motorcycle may result in tire damage, loss of control, or severe injury. Make sure that the total weight of rider, passenger, cargo, and accesso-

ries does not exceed the specified maximum load for the vehicle.

- **Do not carry along loosely packed items, which can shift during a ride.**
- **Securely pack the heaviest items close to the center of the motorcycle and distribute the weight evenly on both sides.**
- **Adjust the suspension and tire air pressure with regard to the load.**
- **Check the tire condition and air pressure before each ride.**

Tire inspection

The tires must be checked before each ride. If the center tread depth reaches the specified limit, if the tire has a nail or glass fragments in it, or if the sidewall is cracked, have a Yamaha dealer replace the tire immediately.

Minimum tire tread depth (front and rear)	1.6 mm
--	--------

NOTE:

The tire tread depth limits may differ from country to country. Always comply with the local regulations.

PERIODIC MAINTENANCE AND MINOR REPAIR

EW000079

EW000078

EAU00681

WARNING

- Have a Yamaha dealer replace excessively worn tires. Besides being illegal, operating the motorcycle with excessively worn tires decreases riding stability and can lead to loss of control.
- The replacement of all wheel- and brake-related parts, including the tires, should be left to a Yamaha dealer, who has the necessary professional knowledge and experience.

Tire information

This motorcycle is equipped with tube tires.

WARNING

- The front and rear tires should be of the same make and design, otherwise the handling characteristics of the motorcycle cannot be guaranteed.
- After extensive tests, only the tires listed below have been approved for this model by Yamaha Motor Co., Ltd.

FRONT (XVS650)

Manufacturer	Size	Model
Bridgestone	100/90-19 57S	L309
Dunlop	100/90-19 57S	F24

REAR (XVS650)

Manufacturer	Size	Model
Bridgestone	170/80-15 M/C 77S	G546
Dunlop	170/80-15 M/C 77S	K555

FRONT (XVS650A)

Manufacturer	Size	Model
Bridgestone	130/90-16 67S	G703
Dunlop	130/90-16 67S	D404F

REAR (XVS650A)

Manufacturer	Size	Model
Bridgestone	170/80-15 M/C 77S	G702
Dunlop	170/80-15 M/C 77S	D404G

WARNING

- Have a Yamaha dealer replace excessively worn tires. Besides being illegal, operating the motorcycle with excessively worn tires decreases riding stability and can lead to loss of control.
- The replacement of all wheel- and brake-related parts, including the tires, should be left to a Yamaha dealer, who has the necessary professional knowledge and experience.
- It is not recommended to patch a punctured tube. If unavoidable, however, patch the tube very carefully and replace it as soon as possible with a high-quality product.


PERIODIC MAINTENANCE AND MINOR REPAIR

Spoke wheels

EAU00685

To maximize the performance, durability, and safe operation of your motorcycle, note the following points regarding the specified wheels.

- The wheel rims should be checked for cracks, bends or warpage, and the spokes for looseness or damage before each ride. If any damage is found, have a Yamaha dealer replace the wheel. Do not attempt even the smallest repair to the wheel. A deformed or cracked wheel must be replaced.
- The wheel should be balanced whenever either the tire or wheel has been changed or replaced. An unbalanced wheel can result in poor performance, adverse handling characteristics, and a shortened tire life.
- Ride at moderate speeds after changing a tire since the tire surface must first be “broken in” for it to develop its optimal characteristics.




1. Locknut
2. Clutch lever free play adjusting bolt
- c. Clutch lever free play

EAU00694

Adjusting the clutch lever free play

The clutch lever free play should measure 10–15 mm as shown. Periodically check the clutch lever free play and, if necessary, adjust it as follows.

1. Loosen the locknut at the clutch lever.
2. To increase the clutch lever free play, turn the adjusting bolt in direction (a). To decrease the clutch lever free play, turn the adjusting bolt in direction (b).




1. Clutch lever free play adjusting nut
2. Locknut


3. If the specified clutch lever free play could be obtained as described above, tighten the locknut and skip the rest of the procedure, otherwise proceed as follows.
4. Fully turn the adjusting bolt at the clutch lever in direction (a) to loosen the clutch cable.
5. Loosen the locknut at the crankcase.
6. To increase the clutch lever free play, turn the adjusting nut in direction (a). To decrease the clutch lever free play, turn the adjusting nut in direction (b).

PERIODIC MAINTENANCE AND MINOR REPAIR

7. Tighten the locknut at the clutch lever and the crankcase.



1. Locknut
2. Brake lever free play adjusting bolt



a. Brake lever free play

Adjusting the brake lever free play

The brake lever free play should measure 10–15 mm as shown. Periodically check the brake lever free play and, if necessary, adjust it as follows.

1. Loosen the locknut at the brake lever.
2. To increase the brake lever free play, turn the adjusting bolt in direction ①. To decrease the brake lever free play, turn the adjusting bolt in direction ②.
3. Tighten the locknut.


EAU00696

PERIODIC MAINTENANCE AND MINOR REPAIR

EW000099

⚠ WARNING

- After adjusting the brake lever free play, check the free play and make sure that the brake is working properly.
- A soft or spongy feeling in the brake lever can indicate the presence of air in the hydraulic system. If there is air in the hydraulic system, have a Yamaha dealer bleed the system before operating the motorcycle. Air in the hydraulic system will diminish the braking performance, which may result in loss of control and an accident.



- a. Distance between brake pedal and footrest
- b. Brake pedal free play

EAU00711*

Adjusting the brake pedal position and free play


EW000104

⚠ WARNING

It is advisable to have a Yamaha dealer make these adjustments.

NOTE:

The brake pedal position should be adjusted before adjusting the brake pedal free play.




- a. Distance between brake pedal and footrest

Brake pedal position

The brake pedal should be positioned approximately 85 mm [XVS650] or 108 mm [XVS650A] above the top of the footrest as shown. Periodically check the brake pedal position and, if necessary, adjust it as follows.

PERIODIC MAINTENANCE AND MINOR REPAIR




1. Locknut
2. Brake pedal position adjusting bolt

1. Loosen the locknut at the brake pedal.
2. To raise the brake pedal, turn the adjusting bolt in direction Ⓐ. To lower the brake pedal, turn the adjusting bolt in direction Ⓑ.
3. Tighten the locknut.

EW000105

⚠ WARNING

After adjusting the brake pedal height, the brake pedal free play must be adjusted.




1. Brake pedal free play adjusting nut

Brake pedal free play

The brake pedal free play should measure 20–30 mm at the brake pedal end. Periodically check the brake pedal free play and, if necessary, adjust it as follows.

To increase the brake pedal free play, turn the adjusting nut at the brake rod in direction Ⓐ. To decrease the brake pedal free play, turn the adjusting nut in direction Ⓑ.



1. Rear brake light switch
2. Rear brake light switch adjusting nut

EAU00713

Adjusting the rear brake light switch

The rear brake light switch, which is activated by the brake pedal, is properly adjusted when the brake light comes on just before braking takes effect. If necessary, adjust the brake light switch as follows.


Turn the adjusting nut while holding the rear brake light switch in place. To make the brake light come on earlier, turn the adjusting nut in direction Ⓐ. To make the brake light come on later, turn the adjusting nut in direction Ⓑ.

PERIODIC MAINTENANCE AND MINOR REPAIR

Checking the front brake pads and rear brake shoes

EAU00720

The front brake pads and the rear brake shoes must be checked for wear at the intervals specified in the periodic maintenance and lubrication chart.




1. Brake pad wear indicator groove

EAU01119

Front brake pads

Each front brake pad is provided with wear indicator grooves, which allow you to check the brake pad wear without having to disassemble the brake. To check the brake pad wear, check the wear indicator grooves. If a brake pad has worn to the point that the wear indicators have almost disappeared, have a Yamaha dealer replace the brake pads as a set.




1. Brake shoe wear limit line
2. Brake shoe wear indicator

EAU00727

Rear brake shoes

The rear brake is provided with a wear indicator, which allows you to check the brake shoe wear without having to disassemble the brake. To check the brake shoe wear, check the position of the wear indicator while applying the brake. If a brake shoe has worn to the point that the wear indicator reaches the wear limit line, have a Yamaha dealer replace the brake shoes as a set.

PERIODIC MAINTENANCE AND MINOR REPAIR



1. Front brake reservoir
2. Minimum level mark

EAU03776

Checking the brake fluid level

Insufficient brake fluid may allow air to enter the brake system, possibly causing it to become ineffective.

Before riding, check that the brake fluid is above the minimum level mark and replenish if necessary. A low brake fluid level may indicate worn brake pads and/or brake system leakage. If the brake level is low, be sure to check the brake pads for wear and the brake system for leakage.

Observe these precautions:

- When checking the fluid level, make sure that the top of the brake fluid reservoir is level.
- Use only the recommended quality brake fluid, otherwise the rubber seals may deteriorate, causing leakage and poor braking performance.

Recommended brake fluid: DOT 4

- Refill with the same type of brake fluid. Mixing fluids may result in a harmful chemical reaction and lead to poor braking performance.
- Be careful that water does not enter the brake fluid reservoir when refilling. Water will significantly lower the boiling point of the fluid and may result in vapor lock.
- Brake fluid may deteriorate painted surfaces or plastic parts. Always clean up spilled fluid immediately.

- As the brake pads wear, it is normal for the brake fluid level to gradually go down. However, if the brake fluid level goes down suddenly, have a Yamaha dealer check the cause.

PERIODIC MAINTENANCE AND MINOR REPAIR

Changing the brake fluid

EAU03238

Have a Yamaha dealer change the brake fluid at the intervals specified in the periodic maintenance and lubrication chart. In addition, have the oil seals of the brake master cylinder and caliper as well as the brake hose replaced at the intervals listed below or whenever they are damaged or leaking.

- Oil seals: Replace every two years.
- Brake hose: Replace every four years.

Checking and lubricating the cables

EAU02962

The operation of all control cables and the condition of the cables should be checked before each ride, and the cables and cable ends should be lubricated if necessary. If a cable is damaged or does not move smoothly, have a Yamaha dealer check or replace it.

Recommended lubricant:
Engine oil

EW000112

WARNING

Damage to the outer sheath may interfere with proper cable operation and will cause the inner cable to rust. Replace a damaged cable as soon as possible to prevent unsafe conditions.

Checking and lubricating the throttle grip and cable

EAU03764

The operation of the throttle grip and the condition of the throttle cable should be checked before each ride, and the cable should be lubricated or replaced if necessary.

NOTE: _____
Since the throttle grip must be removed to access the throttle cable end, the throttle grip and the cable should always be lubricated at the same time.

1. Remove the throttle grip by removing the screws.
2. Hold up the throttle cable, and then apply several drops of oil to the cable, allowing it to trickle into the sheaths.
3. Grease the inside of the throttle grip housing.
4. Grease the metal-to-metal contact surface of the throttle grip, and then install the grip by installing the screws.

PERIODIC MAINTENANCE AND MINOR REPAIR



Recommended lubricant:

Throttle cable:

Engine oil

Throttle grip housing and grip:

Lithium-soap-based grease
(all-purpose grease)



Checking and lubricating the brake and shift pedals

EAU03370

The operation of the brake and shift pedals should be checked before each ride, and the pedal pivots should be lubricated if necessary.

Recommended lubricant:

Lithium-soap-based grease
(all-purpose grease)

Checking and lubricating the brake and clutch levers


EAU03164

The operation of the brake and clutch levers should be checked before each ride, and the lever pivots should be lubricated if necessary.

Recommended lubricant:

Lithium-soap-based grease
(all-purpose grease)

PERIODIC MAINTENANCE AND MINOR REPAIR



Recommended lubricant:
Lithium-soap-based grease
(all-purpose grease)

EAU02939

Checking the front fork

The condition and operation of the front fork must be checked as follows at the intervals specified in the periodic maintenance and lubrication chart.

To check the condition

EW000115

! WARNING

Securely support the motorcycle so that there is no danger of it falling over.

Check the inner tubes for scratches, damage and excessive oil leakage.

EAU03165

Checking and lubricating the sidestand



The operation of the sidestand should be checked before each ride, and the sidestand pivot and metal-to-metal contact surfaces should be lubricated if necessary.

EW000113

! WARNING

If the sidestand does not move up and down smoothly, have a Yamaha dealer check or repair it.

PERIODIC MAINTENANCE AND MINOR REPAIR



2. Hold the lower ends of the front fork legs and try to move them forward and backward. If any free play can be felt, have a Yamaha dealer check or repair the steering.

To check the operation

1. Place the motorcycle on a level surface and hold it in an upright position.
2. While applying the front brake, push down hard on the handlebars several times to check if the front fork compresses and rebounds smoothly.

EC000098

CAUTION:

If any damage is found or the front fork does not operate smoothly, have a Yamaha dealer check or repair it.

EAU00794

Checking the steering

Worn or loose steering bearings may cause danger. Therefore, the operation of the steering must be checked as follows at the intervals specified in the periodic maintenance and lubrication chart.

1. Place a stand under the engine to raise the front wheel off the ground.

EW000115

⚠ WARNING

Securely support the motorcycle so that there is no danger of it falling over.

PERIODIC MAINTENANCE AND MINOR REPAIR

Checking the wheel bearings

EAU01144

The front and rear wheel bearings must be checked at the intervals specified in the periodic maintenance and lubrication chart. If there is play in the wheel hub or if the wheel does not turn smoothly, have a Yamaha dealer check the wheel bearings.

Battery

EAU00800

This motorcycle is equipped with a sealed-type (MF) battery, which does not require any maintenance. There is no need to check the electrolyte or to add distilled water.

EC000101

CAUTION: _____

Never attempt to remove the battery cell seals, as this would permanently damage the battery.

EW000116

WARNING _____

- **Electrolyte is poisonous and dangerous since it contains sulfuric acid, which causes severe burns. Avoid any contact with skin, eyes or clothing and always shield your eyes when working near batteries. In case of contact, administer the following FIRST AID.**
 - **EXTERNAL:** Flush with plenty of water.

- **INTERNAL:** Drink large quantities of water or milk and immediately call a physician.
 - **EYES:** Flush with water for 15 minutes and seek prompt medical attention.
 - **Batteries produce explosive hydrogen gas. Therefore, keep sparks, flames, cigarettes, etc., away from the battery and provide sufficient ventilation when charging it in an enclosed space.**
 - **KEEP THIS AND ALL BATTERIES OUT OF THE REACH OF CHILDREN.**
-

PERIODIC MAINTENANCE AND MINOR REPAIR

To charge the battery

Have a Yamaha dealer charge the battery as soon as possible if it seems to have discharged. Keep in mind that the battery tends to discharge more quickly if the motorcycle is equipped with optional electrical accessories.

To store the battery

1. If the motorcycle will not be used for more than one month, remove the battery, fully charge it, and then place it in a cool, dry place.
2. If the battery will be stored for more than two months, check it at least once a month and fully charge it if necessary.
3. Fully charge the battery before installation.
4. After installation, make sure that the battery leads are properly connected to the battery terminals.


EC000102

CAUTION:

- **Always keep the battery charged. Storing a discharged battery can cause permanent battery damage.**
 - **To charge a sealed-type (MF) battery, a special (constant-voltage) battery charger is required. Using a conventional battery charger will damage the battery. If you do not have access to a sealed-type (MF) battery charger, have a Yamaha dealer charge your battery.**
-

PERIODIC MAINTENANCE AND MINOR REPAIR

EC000103



1. Fuse box
2. Main fuse
3. Spare main fuse


EAU00825

Replacing the fuses

The fuses are located behind panel B. (See page 6-6 for panel removal and installation procedures.)

If a fuse is blown, replace it as follows.

1. Turn the key to "OFF" and turn off the electrical circuit in question.
2. Remove the blown fuse, and then install a new fuse of the specified amperage.



1. Ignition fuse
2. Signaling system fuse
3. Headlight fuse
4. Carburetor heater fuse
5. Spare fuse

Specified fuses:


Main fuse:	30 A
Ignition fuse:	10 A
Signaling system fuse:	10 A
Headlight fuse:	15 A
Carburetor heater fuse:	15 A

CAUTION:

Do not use a fuse of a higher amperage rating than recommended to avoid causing extensive damage to the electrical system and possibly a fire.

3. Turn the key to "ON" and turn on the electrical circuit in question to check if the device operates.
4. If the fuse immediately blows again, have a Yamaha dealer check the electrical system.

PERIODIC MAINTENANCE AND MINOR REPAIR




1. Screw (x 2)

EAU00834


Replacing the headlight bulb

This motorcycle is equipped with a quartz bulb headlight. If the headlight bulb burns out, replace it as follows.

1. Remove the headlight unit by removing the screws.



1. Headlight coupler
 2. Headlight bulb cover
2. Disconnect the headlight coupler, and then remove the headlight bulb cover.



1. Headlight bulb holder
3. Unhook the headlight bulb holder, and then remove the defective bulb.

EW000119

WARNING

Headlight bulbs get very hot. Therefore, keep flammable products away from a lit headlight bulb, and do not touch the bulb until it has cooled down.

4. Place a new bulb into position, and then secure it with the bulb holder.


PERIODIC MAINTENANCE AND MINOR REPAIR

EC000105

CAUTION:

Do not touch the glass part of the headlight bulb to keep it free from oil, otherwise the transparency of the glass, the luminosity of the bulb, and the bulb life will be adversely affected. Thoroughly clean off any dirt and fingerprints on the headlight bulb using a cloth moistened with alcohol or thinner.

5. Install the bulb cover, and then connect the coupler.
6. Install the headlight unit by installing the screws.
7. Have a Yamaha dealer adjust the headlight beam if necessary.




1. Screw (x 2)

EAU00855

Replacing a turn signal light bulb or the tail/brake light bulb

1. Remove the lens by removing the screws.
2. Remove the defective bulb by pushing it in and turning it counter-clockwise.



1. Screw (x 2)


3. Insert a new bulb into the socket, push it in, and then turn it clockwise until it stops.
4. Install the lens by installing the screws.

EC000108

CAUTION:

Do not overtighten the screws, otherwise the lens may break.

PERIODIC MAINTENANCE AND MINOR REPAIR



1. Screw (x 3)

EAU01579

Supporting the motorcycle

Since this model is not equipped with a centerstand, follow these precautions when removing the front and rear wheel or performing other maintenance requiring the motorcycle to stand upright. Check that the motorcycle is in a stable and level position before starting any maintenance. A strong wooden box can be placed under the engine for added stability.


To service the rear wheel

Raise the rear wheel off the ground by using a motorcycle stand or, if a motorcycle stand is not available, by placing a jack either under each side of the frame in front of the rear wheel or under each side of the swingarm.

To service the front wheel


1. Stabilize the rear of the motorcycle by using a motorcycle stand or, if an additional motorcycle stand is not available, by placing a jack under the frame in front of the rear wheel.
2. Raise the front wheel off the ground by using a motorcycle stand.

PERIODIC MAINTENANCE AND MINOR REPAIR




1. Speedometer cable

EAU03239



1. Wheel axle
2. Front wheel axle pinch bolt



1. Speedometer gear unit
2. Speedometer cable

EAU01394

Front wheel

To remove the front wheel

EW000122

! WARNING

- It is advisable to have a Yamaha dealer service the wheel.
- Securely support the motorcycle so that there is no danger of it falling over.

1. Disconnect the speedometer cable from the front wheel.

2. Loosen the front wheel axle pinch bolt, then the wheel axle.
3. Lift the front wheel off the ground according to the procedure on page 6-34.
4. Pull the wheel axle out, and then remove the wheel.

ECA00048

CAUTION:

Do not apply the brake after the wheel has been removed together with the brake disc, otherwise the brake pads will be forced shut.

To install the front wheel

1. Install the speedometer gear unit into the wheel hub so that the projections mesh with the slots.
2. Lift the wheel up between the fork legs.

NOTE:

Make sure that there is enough space between the brake pads before inserting the brake disc and that the slot in the speedometer gear unit fits over the retainer on the fork leg.

3. Insert the wheel axle.

PERIODIC MAINTENANCE AND MINOR REPAIR

4. Lower the front wheel so that it is on the ground.
5. Push down hard on the handlebar several times to check for proper fork operation.
6. Tighten the wheel axle to the specified torque.

Tightening torque:

Wheel axle:
59 Nm (5.9 m·kg)

7. Install the front wheel axle pinch bolt, and then tighten it to the specified torque.

Tightening torque:

Front wheel axle pinch bolt:
20 Nm (2.0 m·kg)

8. Connect the speedometer cable.

Rear wheel

To remove the rear wheel


⚠ WARNING

- It is advisable to have a Yamaha dealer service the wheel.
- Securely support the motorcycle so that there is no danger of it falling over.

1. Loosen the axle nut.

EAU01350


EW000122



1. Brake pedal free play adjusting nut
2. Brake camshaft lever
3. Brake rod
4. Bolt (shoe plate)
5. Brake torque rod
6. Bolt (swingarm)

2. Disconnect the brake torque rod from the brake shoe plate by removing the bolt.
3. Loosen the brake torque rod bolt at the swingarm.
4. Remove the brake pedal free play adjusting nut, and then disconnect the brake rod from the brake camshaft lever.
5. Remove panel A. (See page 6-5 for panel removal and installation procedures.)


PERIODIC MAINTENANCE AND MINOR REPAIR



1. Bolt (× 4)
2. Final gear case
3. Axle nut

6. Remove the bolts that secure the final gear case to the swingarm.
7. Lift the rear wheel off the ground according to the procedure on page 6-34.
8. While supporting the drive shaft, pull the rear wheel back to remove the following parts as an assembly: wheel, wheel axle, final gear case, and drive shaft.

NOTE: _____
Make sure to support the drive shaft as it is being pulled out.



1. Middle gear universal joint
2. Drive shaft

EAU01563

To install the rear wheel

1. Install the rear wheel, wheel axle, final gear case, and drive shaft by pushing the wheel forward and guiding the drive shaft into the middle gear universal joint.
2. Install the final gear case bolts, and then tighten them to the specified torque.

Tightening torque:
Final gear case bolt:
90 Nm (9.0 m·kg)

3. Install the brake rod onto the brake camshaft lever, and then install the brake pedal free play adjusting nut onto the brake rod.
4. Install the brake torque rod bolts, and then tighten them to the specified torque.

Tightening torque:
Brake torque rod bolt:
20 Nm (2.0 m·kg)

5. Install the panel.
6. Lower the rear wheel so that it is on the ground.
7. Tighten the axle nut to the specified torque.

Tightening torque:
Axle nut:
92 Nm (9.2 m·kg)

8. Adjust the brake pedal free play. (See page 6-21 for brake pedal free play adjustment procedures.)

EW000103

EAU01008

WARNING

After adjusting the brake pedal free play, check the operation of the brake light.

Troubleshooting

Although Yamaha motorcycles receive a thorough inspection before shipment from the factory, trouble may occur during operation. Any problem in the fuel, compression, or ignition systems, for example, can cause poor starting and loss of power.

The following troubleshooting chart represents a quick and easy procedure for checking these vital systems yourself. However, should your motorcycle require any repair, take it to a Yamaha dealer, whose skilled technicians have the necessary tools, experience, and know-how to service the motorcycle properly.

Use only genuine Yamaha replacement parts. Imitation parts may look like Yamaha parts, but they are often inferior, have a shorter service life and can lead to expensive repair bills.

PERIODIC MAINTENANCE AND MINOR REPAIR

Troubleshooting chart

EAU01297


EW000125




WARNING

Keep away from open flames and do not smoke while checking or working on the fuel system.


1. Fuel




2. Compression



3. Ignition



4. Battery



MOTORCYCLE CARE AND STORAGE

Care	7-1
Storage	7-4

Care

While the open design of a motorcycle reveals the attractiveness of the technology, it also makes it more vulnerable. Rust and corrosion can develop even if high-quality components are used. A rusty exhaust pipe may go unnoticed on a car, however, it detracts from the overall appearance of a motorcycle. Frequent and proper care does not only comply with the terms of the warranty, but it will also keep your motorcycle looking good, extend its life and optimize its performance.

Before cleaning

1. Cover the muffler outlets with plastic bags after the engine has cooled down.
2. Make sure that all caps and covers as well as all electrical couplers and connectors, including the spark plug caps, are tightly installed.
3. Remove extremely stubborn dirt, like oil burnt onto the crankcase, with a degreasing agent and a brush, but never apply such products onto seals, gaskets and wheel axles. Always rinse the dirt and degreaser off with water.

Cleaning

ECA00010

CAUTION:

- **Avoid using strong acidic wheel cleaners, especially on spoked wheels. If such products are used on hard-to-remove dirt, do not leave the cleaner on the affected area any longer than instructed. Also, thoroughly rinse the area off with water, immediately dry it, and then apply a corrosion protection spray.**
- **Improper cleaning can damage windshields, cowlings, panels and other plastic parts. Use only a soft, clean cloth or sponge with mild detergent and water to clean plastic.**

MOTORCYCLE CARE AND STORAGE

- Do not use any harsh chemical products on plastic parts. Be sure to avoid using cloths or sponges which have been in contact with strong or abrasive cleaning products, solvent or thinner, fuel (gasoline), rust removers or inhibitors, brake fluid, antifreeze or electrolyte.
 - Do not use high-pressure washers or steam-jet cleaners since they cause water seepage and deterioration in the following areas: seals (of wheel and swing-arm bearings, fork and brakes), electric components (couplers, connectors, instruments, switches and lights), breather hoses and vents.
 - For motorcycles equipped with a windshield: Do not use strong cleaners or hard sponges as they will cause dulling or scratching. Some cleaning compounds for plastic may leave scratches on the windshield. Test the product on a small hidden part of the windshield to make sure that it does not leave any marks. If the windshield is scratched, use a quality plastic polishing compound after washing.
-

After normal use

Remove dirt with warm water, a mild detergent, and a soft, clean sponge, and then rinse thoroughly with clean water. Use a toothbrush or bottlebrush for hard-to-reach areas. Stubborn dirt and insects will come off more easily if the area is covered with a wet cloth for a few minutes before cleaning.

After riding in the rain, near the sea or on salt-sprayed roads

Since sea salt or salt sprayed on roads during winter are extremely corrosive in combination with water, carry out the following steps after each ride in the rain, near the sea or on salt-sprayed roads.

NOTE: _____
Salt sprayed on roads in the winter may remain well into spring.

MOTORCYCLE CARE AND STORAGE

1. Clean the motorcycle with cold water and a mild detergent, after the engine has cooled down.

ECA00012

CAUTION: _____

Do not use warm water since it increases the corrosive action of the salt.

2. After drying the motorcycle, apply a corrosion protection spray on all metal, including chrome- and nickel-plated, surfaces to prevent corrosion.

After cleaning

1. Dry the motorcycle with a chamois or an absorbing cloth.
2. Use a chrome polish to shine chrome, aluminum and stainless-steel parts, including the exhaust system. (Even the thermally induced discoloring of stainless-steel exhaust systems can be removed through polishing.)

3. To prevent corrosion, it is recommended to apply a corrosion protection spray on all metal, including chrome- and nickel-plated, surfaces.
4. Use spray oil as a universal cleaner to remove any remaining dirt.
5. Touch up minor paint damage caused by stones, etc.
6. Wax all painted surfaces.
7. Let the motorcycle dry completely before storing or covering it.

EWA00031

⚠ WARNING _____

- **Make sure that there is no oil or wax on the brakes or tires.**
 - **If necessary, clean the brake discs and brake linings with a regular brake disc cleaner or acetone, and wash the tires with warm water and a mild detergent. Before riding at higher speeds, test the motorcycle's braking performance and cornering behavior.**
-

ECA00013

CAUTION: _____

- **Apply spray oil and wax sparingly and make sure to wipe off any excess.**
 - **Never apply oil or wax to any rubber and plastic parts, but treat them with a suitable care product.**
 - **Avoid using abrasive polishing compounds as they will wear away the paint.**
-

NOTE: _____

Consult a Yamaha dealer for advice on what products to use.

MOTORCYCLE CARE AND STORAGE

Storage

Short-term

Always store your motorcycle in a cool, dry place and, if necessary, protect it against dust with a porous cover.

ECA00014

CAUTION:

- **Storing the motorcycle in a poorly ventilated room or covering it with a tarp, while it is still wet, will allow water and humidity to seep in and cause rust.**
- **To prevent corrosion, avoid damp cellars, stables (because of the presence of ammonia) and areas where strong chemicals are stored.**

Long-term

Before storing your motorcycle for several months:

1. Follow all the instructions in the “Care” section of this chapter.
2. For motorcycles equipped with a fuel cock that has an “OFF” position: Turn the fuel cock lever to “OFF”.
3. Drain the carburetor float chambers by loosening the drain bolts; this will prevent fuel deposits from building up. Pour the drained fuel into the fuel tank.
4. Fill up the fuel tank and add fuel stabilizer (if available) to prevent the fuel tank from rusting and the fuel from deteriorating.
5. Perform the following steps to protect the cylinders, piston rings, etc. from corrosion.
 - a. Remove the spark plug caps and spark plugs.
 - b. Pour a teaspoonful of engine oil into each spark plug bore.

- c. Install the spark plug caps onto the spark plugs, and then place the spark plugs on the cylinder head so that the electrodes are grounded. (This will limit sparking during the next step.)
- d. Turn the engine over several times with the starter. (This will coat the cylinder walls with oil.)
- e. Remove the spark plug caps from the spark plugs, and then install the spark plugs and the spark plug caps.

EWA00003

WARNING

To prevent damage or injury from sparking, make sure to ground the spark plug electrodes while turning the engine over.

6. Lubricate all control cables and the pivoting points of all levers and pedals as well as of the sidestand/centerstand.

MOTORCYCLE CARE AND STORAGE

7. Check and, if necessary, correct the tire air pressure, and then lift the motorcycle so that both of its wheels are off the ground. Alternatively, turn the wheels a little every month in order to prevent the tires from becoming degraded in one spot.
8. Cover the muffler outlets with plastic bags to prevent moisture from entering them.
9. Remove the battery and fully charge it. Store it in a cool, dry place and charge it once a month. Do not store the battery in an excessively cold or warm place (less than 0 °C or more than 30 °C). For more information on storing the battery, see page 6-30.

NOTE: _____
Make any necessary repairs before storing the motorcycle.

Specifications 8-1
Conversion table 8-6

Specifications

Model XVS650/XVS650A

Dimensions

XVS650

Overall length	2,340 mm
Overall width	880 mm
Overall height	1,070 mm
Seat height	695 mm
Wheelbase	1,610 mm
Ground clearance	140 mm
Minimum turning radius	3,100 mm

XVS650A

Overall length	2,450 mm
Overall width	930 mm
Overall height	1,105 mm
Seat height	710 mm
Wheelbase	1,625 mm
Ground clearance	145 mm
Minimum turning radius	3,400 mm

Basic weight (with oil and full fuel tank)


XVS650	233 kg
XVS650A	247 kg

Engine

Engine type	Air-cooled 4-stroke, SOHC
Cylinder arrangement	V-type 2-cylinder
Displacement	649 cm ³
Bore × stroke	81 × 63 mm
Compression ratio	9:1
Starting system	Electric starter
Lubrication system	Wet sump

Engine oil

Type



Recommended engine oil classification

API Service SE, SF, SG type or higher

CAUTION:

Be sure to use motor oils that do not contain anti-friction modifiers. Passenger car motor oils (often labeled “ENERGY CONSERVING II”) contain anti-friction additives which will cause clutch and/or starter clutch slippage, resulting in reduced component life and poor engine performance.

Quantity

Without oil filter element replacement	2.6 L
With oil filter element replacement	2.8 L
Total amount (dry engine)	3.2 L

Final gear oil

Type	Hypoid gear oil SAE 80 (API GL4) or multigrade hypoid gear oil SAE 80W-90
Final gear case capacity	0.19 L

Air filter

Dry type element

Fuel

Type	Regular unleaded gasoline
Fuel tank capacity	16 L
Reserve amount	3 L

Carburetor

Manufacturer	MIKUNI
Model × quantity	BDS28 × 2

Spark plug

Manufacturer/model NGK / DPR7EA-9 or DENSO / X22EPR-U9

Gap 0.8–0.9 mm

Clutch type

Wet, multiple-disc

Transmission

Primary reduction system	Spur gear
Primary reduction ratio	1.789
Secondary reduction system	Shaft drive
Secondary reduction ratio	3.070
Transmission type	Constant-mesh 5-speed
Operation	Left foot
Gear ratio	1st 2.714 2nd 1.900 3rd 1.458 4th 1.167 5th 0.967

Chassis

Frame type	Double cradle
Caster angle	35°
Trail	
XVS650	153 mm
XVS650A	145 mm

SPECIFICATIONS

Tires

XVS650

Front

Type	Tube tire
Size	100/90-19 57S
Manufacturer/model	Bridgestone / L309 Dunlop / F24

Rear

Type	Tube tire
Size	170/80-15 M/C 77S
Manufacturer/model	Bridgestone / G546 Dunlop / K555

Maximum load* 180 kg

Tire air pressure (measured on cold tires)

Up to 90 kg*

Front	200 kPa (2.00 kg/cm ² , 2.00 bar)
Rear	225 kPa (2.25 kg/cm ² , 2.25 bar)

90 kg–maximum*

Front	200 kPa (2.00 kg/cm ² , 2.00 bar)
Rear	250 kPa (2.50 kg/cm ² , 2.50 bar)

* Total weight of rider, passenger, cargo and accessories

XVS650A

Front

Type	Tube tire
Size	130/90-16 67S
Manufacturer/model	Bridgestone / G703 Dunlop / D404F

Rear

Type	Tube tire
Size	170/80-15 M/C 77S
Manufacturer/model	Bridgestone / G702 Dunlop / D404G

Maximum load* 200 kg

Tire air pressure (measured on cold tires)

Up to 90 kg*

Front	225 kPa (2.25 kg/cm ² , 2.25 bar)
Rear	225 kPa (2.25 kg/cm ² , 2.25 bar)

90 kg–maximum*

Front	225 kPa (2.25 kg/cm ² , 2.25 bar)
Rear	250 kPa (2.50 kg/cm ² , 2.50 bar)

* Total weight of rider, passenger, cargo and accessories

Wheels

XVS650

Front

Type Spoke wheel
 Size 19 × MT 2.50

Rear

Type Spoke wheel
 Size 15 M/C × MT 3.50

XVS650A

Front

Type Spoke wheel
 Size 16 × MT 3.00

Rear

Type Spoke wheel
 Size 15 M/C × MT 3.50

Brakes

Front

Type Single disc brake
 Operation Right hand
 Fluid DOT 4

Rear

Type Drum brake
 Operation Right foot

Suspension

Front Telescopic fork
 Rear Swingarm (monocross)

Spring/shock absorber

Front Coil spring / oil damper
 Rear Coil spring / gas-oil damper

Wheel travel

XVS650

Front 140 mm
 Rear 86 mm

XVS650A

Front 140 mm
 Rear 98 mm

Electrical systems

Ignition system Transistorized coil ignition (digital)

Charging system

Type A.C. magneto
 Standard output 14 V, 20 A @ 5,000 r/min

Battery

Type GT12B-4
 Voltage, capacity 12 V, 10 Ah

Headlight type

Quartz bulb (halogen)

SPECIFICATIONS

Bulb voltage, wattage × quantity

Headlight	12 V, 60/55 W × 1
Auxiliary light	12 V, 4 W × 1
Tail/brake light	12 V, 5/21 W × 1
Turn signal light	12 V, 21 W × 4
Meter lighting	12 V, 1.7 W × 1
Neutral indicator light	12 V, 1.7 W × 1
High beam indicator light	12 V, 1.7 W × 1
Turn signal indicator light	12 V, 1.7 W × 1
Engine trouble warning light	12 V, 1.7 W × 1

Fuses

Main fuse	30 A
Ignition fuse	10 A
Signaling system fuse	10 A
Headlight fuse	15 A
Carburetor heater fuse	15 A

EAU01064

Conversion table

All specification data in this manual are listed in SI and METRIC UNITS.

Use this table to convert METRIC unit data to IMPERIAL unit data.

Example

METRIC		MULTIPLIER		IMPERIAL
** mm	×	0.03937	=	** in
2 mm	×	0.03937	=	0.08 in

Conversion table


METRIC TO IMPERIAL			
	Metric unit	Multiplier	Imperial unit
Torque	m·kg	7.233	ft·lb
	m·kg	86.794	in·lb
	cm·kg	0.0723	ft·lb
	cm·kg	0.8679	in·lb
Weight	kg	2.205	lb
	g	0.03527	oz
Speed	km/h	0.6214	mi/h
Distance	km	0.6214	mi
	m	3.281	ft
	m	1.094	yd
	cm	0.3937	in
	mm	0.03937	in
Volume, Capacity	cc (cm ³)	0.03527	oz (IMP liq.)
	cc (cm ³)	0.06102	cu-in
	L (liter)	0.8799	qt (IMP liq.)
	L (liter)	0.2199	gal (IMP liq.)
Miscellaneous	kg/mm	55.997	lb/in
	kg/cm ²	14.2234	psi (lb/in ²)
	Centigrade (°C)	9/5 + 32	Fahrenheit (°F)

Identification numbers	9-1
Key identification number	9-1
Vehicle identification number	9-1
Model label	9-2

Identification numbers

EAU02944

Record the key identification number, vehicle identification number and model label information in the spaces provided below for assistance when ordering spare parts from a Yamaha dealer or for reference in case the vehicle is stolen.



1. Key identification number

1. KEY IDENTIFICATION NUMBER:


2. VEHICLE IDENTIFICATION NUMBER:

3. MODEL LABEL INFORMATION:

EAU01041

Key identification number

The key identification number is stamped into the key tag. Record this number in the space provided and use it for reference when ordering a new key.



1. Vehicle identification number


EAU01043

Vehicle identification number

The vehicle identification number is stamped into the steering head pipe. Record this number in the space provided.

NOTE:

The vehicle identification number is used to identify your motorcycle and may be used to register your motorcycle with the licensing authority in your area.



1. Model label

EAU01804

Model label

The model label is affixed to the frame under the rider seat. (See page 3-10 [XVS650] or 3-11 [XVS650A] for rider seat removal and installation procedures.) Record the information on this label in the space provided. This information will be needed when ordering spare parts from a Yamaha dealer.

INDEX

A

- Air filter element, cleaning6-13
- Anti-theft alarm3-3

B

- Battery6-29
- Brake and clutch levers, checking
and lubricating6-26
- Brake and shift pedals, checking
and lubricating6-26
- Brake fluid, changing6-25
- Brake fluid level, checking6-24
- Brake lever3-6
- Brake lever free play, adjusting6-20
- Brake light switch (rear), adjusting6-22
- Brake pads and shoes, checking6-23
- Brake pedal3-6
- Brake pedal position and free play,
adjusting6-21

C

- Cables, checking and lubricating6-25
- Carburetors, adjusting6-14
- Care7-1
- Clutch lever3-5
- Clutch lever free play, adjusting6-19
- Conversion table8-6

D

- Dimmer switch3-4

E

- Engine break-in5-4
- Engine oil and oil filter element6-9
- Engine stop switch3-4

- Engine trouble warning light3-2

F

- Final gear oil6-11
- Front fork, checking6-27
- Fuel3-7
- Fuel cock3-8
- Fuel consumption, tips for reducing5-4
- Fuel tank cap3-7
- Fuses, replacing6-31

H

- Handlebar switches3-3
- Headlight bulb, replacing6-32
- Helmet holder3-12
- High beam indicator light3-2
- Horn switch3-4

I

- Identification numbers9-1
- Idling speed, adjusting6-15
- Ignition circuit cut-off system3-16
- Indicator and warning lights3-2

K

- Key identification number9-1

L

- Light switch3-4
- Luggage strap holders3-15

M

- Main switch/steering lock3-1
- Model label9-2

N

- Neutral indicator light3-2

P

- Panels, removing and installing6-5
- Parking5-5
- Part locations2-1
- Pass switch3-4
- Periodic maintenance and
lubrication chart6-2
- Pre-operation check list4-1

S

- Safety information1-1
- Seats (XVS650)3-10
- Passenger seat3-10
- Rider seat3-10
- Seats (XVS650A)3-11
- Passenger seat3-11
- Rider seat3-11
- Shifting5-3
- Shift pedal (XVS650)3-5
- Shift pedal (XVS650A)3-5
- Shock absorber assembly, adjusting3-14
- Sidestand3-15
- Sidestand, checking and lubricating6-27
- Spark plugs, checking6-7
- Specifications8-1
- Speedometer unit3-3
- Starter (choke) knob3-9
- Starting a warm engine5-2
- Starting the engine5-1
- Start switch3-4
- Steering, checking6-28

Storage.....	7-4
Storage compartment	3-13
Supporting the motorcycle	6-34

T

Throttle cable free play, adjusting	6-15
Throttle grip and cable, checking and lubricating.....	6-25
Tires	6-16
Tool kit.....	6-1
Troubleshooting.....	6-38
Troubleshooting chart	6-39
Turn signal indicator light.....	3-2
Turn signal light or tail/brake light bulb, replacing	6-33
Turn signal switch.....	3-3

V

Valve clearance, adjusting.....	6-16
Vehicle identification number	9-1

W

Wheel bearings, checking.....	6-29
Wheel (front).....	6-35
Installing.....	6-35
Removing.....	6-35
Wheel (rear)	6-36
Installing.....	6-37
Removing.....	6-36
Wheels	6-19



PRINTED ON RECYCLED PAPER

PRINTED IN JAPAN
2000·9-0.3×2 CR
(E)